

Canon - PGI-220 / CLI-221

After installing your cartridges, you'll notice the printer still thinks they're empty, despite having just been refilled. This will not prevent you from printing, but you will get a few friendly reminders from the printer that you are using "empty" or refilled cartridges. Simply click OK to these warnings.

The remaining level of the following ink cannot be correctly detected.
Yellow <CLI-221Y>

Replace the ink tank. If you want to continue using this tank, click OK.

When you see one of these messages, simply **press the OK button on the PRINTER** to continue printing.

The following ink may have run out.
Yellow <CLI-221Y>

Replacing the ink tank is recommended. If printing is in progress and you want to continue printing, press the printer's OK button. Then printing can continue. Replacing the ink tank is recommended after the printing. The printer may be damaged if printing is continued under the ink out condition

If there is no option to continue printing (see message below), read the message and follow the steps outlined. You will be prompted to do this once for each of the cartridges refilled. After you've done it, you will never be prompted again for that cartridge.

Press and hold the printer's Stop button for at least 5 seconds, and then release it.

This operation will release the function for detecting the remaining level of the following ink:

Yellow <CLI-221Y>

Notice this message asks you to **hold the printer's STOP Button for 5 seconds**. Follow these instructions and you can continue printing without difficulty