

## **RESETTING THE HP LJ 4000/4050 TONERGAUGE**

After the new toner cartridge is installed, the user must reset the HP TonerGauge from the control panel. When the top cover is closed after installing the new toner cartridge, the **NEW TONER CARTRIDGE=NO** message is displayed on the control panel for approximately 30 seconds. To reset the HP TonerGauge:

- 1 – Press [**- Value +**] until **YES** appears.
- 2 – Press [**Select**] to save the selection.
- 3 – Press [**Go**] to exit the menu.

Note:

If the **NEW TONER CARTIRDGE=NO** message is no longer displayed on the control panel when you replace an empty or low toner cartridge, press [**Menu**] repeatedly until **CONFIGUATION MENU** appears. Press [**Item**] repeatedly until **NEW TONER CARTRIDGE=NO** appears, then complete steps 1 through 3 above.